



Flexible building wrap to comply with Table 23 (E2/AS1, E2/AS4), or have a BRANZ appraisal, or CodeMark.

Timber framing. To comply with the NZBC or have the equivalent stiffness to NZS 3604:2011. Studs @ max 600 mm crs, noggs & dwangs @ max 800 mm crs.

Horizontal batten at soffit

Horizontal cavity battens  
IQ Bat

spacing of 400mm - 600mm centres

Double battens anywhere there is flashings. Top + bottom, all corners and around windows/doors.

Vertical support battens  
for internal and external corners  
IQ Bat

**iQCLAD** ALUMINIUM CLADDING

www.iqclad.nz

scale: 1:20 date: 19.02.2023

title:  
**IQ Bat Vertical Layout**

drawing number:  
**IQW EC 01**